



**C6 CORVETTE CHROME VINYL REAR VALENCE TRIM**  
**Part #042035**

**PARTS INCLUDED:**

- \_\_\_ 1-Pre-Cut Length Molding
- \_\_\_ 1-Adhesive Promoter Pack
- \_\_\_ 1-Test Kit

This new valence trim has been pre sized and shaped especially for your C-6. In the next few steps we will explain just how to prep and install the trim and give your new C-6 a great looking rear-end!

1. Thoroughly clean the rear valence ridge where trim is to be applied with alcohol to remove any wax and dirt. After this step swipe the length of the ridge with the adhesive promoter provided.
2. It is important to make sure that you will have good adhesion so we have included a test strip of attachment tape for you to check the tack. If all is well you may continue installation. If not go through the entire preparation once again.
3. Now that you have successfully prepared the valence ridge you may begin installation by removing a small portion of the red release liner from the back of the trim. Place the trim at one edge of the valence and press firmly to set as you work your way around to the opposite side removing the red liner as you go. As you apply the trim it is important not to stretch the trim by pulling to excess fully. Allow the trim to lay into position as you press firmly. If applied correctly it should not need any trimming at the end of installation. If however you do have any excess trim simply cut it away using a common scissor. Then press firmly to set the end to finish the installation.

**NOTE: DO NOT GET WET FOR 24 HOURS!**

**Care and Maintenance:**

**Wash and wax molding kits regularly to insure a beautiful long lasting finish.**





When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.