



AMERICAN CAR CRAFT INSTRUCTIONS

C6 Z06 Stainless Blakk Laser Mesh Lower Air Dam Grilles

PART # 042100



PARTS INCLUDED:

2-Laser Mesh Grille Inserts w/attachment Tape
2-Black Air Deflector Plates

1. Remove the two factory air dam screws just behind the air dam opening.
2. Set the new grille in position behind the hole and shape the grille by hand so that it matches the shape and contour of the factory air dam and also so that the two holes in the new grille match up with the two screw hole locations.
3. For ease of installation your new grille comes with an attachment tape. Thoroughly clean the area where the two factory screws were removed with rubbing alcohol. Peel the red release liner from the grille and set the grille in position. The tape has been added to allow the grille to remain in place leaving your hands free to re-install the two factory screws. Simply replace the two screws for each of the grilles to complete the installation.