



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE COMPANENT STOCK AIR TUBE COVER

Part #043038patent pending

Items Included:

- _ Air Tube Cover**
- _ 2 1" Washer Head Screws**
- _ 2 White Screw Sockets**
- _ 2 Chrome Screw Cap Covers**

Your new cover comes to you with a protective liner. Do not remove liner until step 3.

Your new air tube cover is designed to attach at the two plastic factory attachment studs.

- 1. Remove the small plastic insert at the very top of the factory stud. This will expose a square hole.**

- 2. Place your new cover into position and check fitment. Although your new cover comes to you pre shaped it will be necessary to form slightly by hand so that the holes in the cover exactly line up with the holes that you just exposed.**

- 3. Once you are satisfied with the fit place one of the two washer head screws (provided) thru one white socket (provided) and gently screw into previously exposed holes. DO NOT TIGHTEN just yet. Start the second screw and adjust cover before final tightening. Remove protective liner. Snap on chrome screw covers (provided).**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.