



## AMERICAN CAR CRAFT INSTRUCTIONS

---

***C6 Corvette Hood Panel Badge (2005-2013 Factory Hood Panel Only)***

***PART #043113***



**PARTS INCLUDED:**

- 1-Main C6 Emblem Backing
- 8-Flag Pieces
- 8-Rivets
- 8-Rivet Washers
- 1-Adhesive Promoter

**PROTECTIVE LINER INFORMATION:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and/or possible scratches during installation.

1. Remove the factory hood panel (pad) by popping all the hood retainers off. Keep these fasteners; they will be re-used to re-install the hood panel.
2. Wipe the indented C6 hood panel emblem with a cleaner to remove any kind of grease or dirt from the road.

3. Use the supplied adhesive promoter packet and wipe the indented C6 hood panel emblem.
4. Pull the Red 3M tape backing off and stick the emblem to the hood pad. Be careful to align the emblem properly the first time. The 3M adhesive is very strong and can make adjustments very difficult.
5. You have been provided with (8) rivets and (8) rivet washers that will need to be installed by drilling through the holes that are counter sunk on the main C6 emblem plate, with the drill provided drill bit.
6. Once the holes have been drilled in the hood panel, place the washers on the back side of the hood panel and rivet the emblem to the hood panel. The main flag pieces will cover the rivets when installation is complete.
7. Use the engraved lines as a guide to install the flag pieces, in the correct locations.
8. Once the emblem has been completely install on the hood panel, reinstall the hood panel with the factory fasteners.



**Thank You and Enjoy Your Purchase!**

**AMERICAN CAR CRAFT**

When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.