



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **Corvette “Stingray” Black/Polished/Carbon Fiber Part #052082**



#### **PARTS INCLUDED:**

- 1-Black/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.00x20mm Metric Hex Head Cap Screws
- 2-124NC 10mm Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

**Thank you and enjoy your purchase!**