



AMERICAN CAR CRAFT INSTRUCTIONS

**CAMARO EXTERIOR DOOR HANDLE PULL TRIM
PART#102003**



PARTS INCLUDED:

2pc Stainless Badge Set
1-Adhesive Promoter Tube

Your badges are designed to be used on the exterior surface of your car and can be placed to any flat surface that you choose.

1. Clean the area to be mounted with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.
2. Place each badge into position to familiarize yourself with each placement before removing the liner. It MAY BE necessary to HAND FORM the badges to CONFORM to the shape of the car doing this will prevent any possibility of the badge popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each badge and carefully set them nice and evenly to your car. Press firmly to set.

When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.