



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO REAR VALANCE TRIM

PART #102021

PARTS INCLUDED:

- ___1-Precut 3/4" Chrome Vinyl Trim**
- ___1-Adhesive Promoter Pack**

The rear valance trim is just the right touch to enhance the broad back valance panel of the New Camaro. This is a pre measured and precut 3/4" chrome vinyl trim kit that will last for years.

The trim comes to you with a blue protective liner. Do not remove this liner until the installation is complete.

1. Thoroughly clean the upper rail of the factory valance. Scrub the area with alcohol to remove all wax and dirt then swipe the area once with the adhesive promoter packet provided.

2. You will notice that the trim has been precut to a slight angle. Match this angle to the valance to determine the right side up. Peel a small length of the red release liner from the back of the trim to create a pull tab. Set the end into position and then press firmly against the trim to create a good bond as you pull the liner along its length until the entire trim is set into position. Use a soft cloth to firmly set the trim in place then remove the protective liner to finish the installation.

NOTE: DO NOT GET WET FOR 24 HOURS!

Care and Maintenance:

Wash and wax molding kits regularly to insure a beautiful long lasting finish.



When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.