



AMERICAN CAR CRAFT INSTRUCTIONS

Camaro Style GM Licensed Rear Tag Frame

PART #102043



Parts Included:

- 1-Chrome/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.0x20mm Zinc Plated Course Head
- 2-124NC 10mmChrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!