



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO SS ENGINE SHROUD V8 TRIM BADGE

PART #103006

PARTS INCLUDED:

- 1-Stainless V8 Trim Kit
- 1-Adhesive Promoter Tube

This small kit had been designed to fit perfectly into the recess of the factory SS engine shroud adding a nice touch and an element of class to the new cover.

1. Thoroughly clean the recesses of the V8 badge in the front of the SS engine shroud with alcohol to remove any and all dirt and road grime that may have accumulated in there.
2. Swipe the recess and V8 area with the adhesive promoter snap tube provided.
3. Peel the red release liner from the back of the trim set and then firmly press them in place. Wipe clean with a micro fiber cloth to finish the installation

