



AMERICAN CAR CRAFT INSTRUCTIONS

OIL FILLER CHROME CAP COVER

PART#103016 PATENT PENDING



PARTS INCLUDED:

- 1-Chrome Cap Cover/Covers
- 1-Adhesive Promoter Pack

These new and unique caps are designed to set over the factory cap as a cosmetic cover only. These chrome plated steel caps are simple to attach and offer a nice clean look.

1. The first step for installation will be to thoroughly scrub the top of the factory cap with alcohol to remove any surface contaminants then swipe the top with the adhesive promoter provided.
2. You have been provided with 2" furry hook and loop fastener attachment cookies on the underside of the cap. Peel the release liner from the back of the cookie and firmly set them to the top of the factory cap.
3. Simply set cap in place.

AMERICAN CAR CRAFT