

AMERICAN CAR CRAFT INSTRUCTION

2008-2010 CHALLENGER LOWER GRILLE TRIM RING

PART # 152017 patent pending



PARTS INCLUDED:

- 1-Stainless Lower Grille Trim Ring
- 1-Length of 1/8" Chrome Molding
- 1-Adhesive Promoter Pack
- 1-Adhesive Promoter Tube

This new trim ring has been designed to offer a really nice finish to the front bumper grille opening. It's the part you didn't realize was missing until you have installed it and it has been made especially to enhance our factory lower grill overlay.

Your new accessory comes to you with a protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

- 1. Thoroughly scrub clean the bumpers insert area with household **Isopropyl Alcohol** (or rubbing alcohol) to remove any and all road grime and waxes.
- 2. Once properly cleaned take a piece of test masking tape and stick the test tape strip to the area in where you will be mounting your new trim. Test several areas, if it is tacky and sticks then proceed to the next step. If it is not sticking very well in any of the spots you tested then re-clean the area until the test strip sticks to all areas. If the test strip tape doesn't stick well neither will your new trim piece.

- **3.** Take the promoter (included) and swipe the entire area where your trim will stick to. This will insure a nice strong bond long term. The promoter is clear and will not damage or stain your paint.
- **4.** Without removing the rear red liner set the trim ring in place to get acquainted with the position as well as just how you will set the ring in place. The attachment tape is very aggressive and will not allow you to reposition the ring once you have set it in position so take your time positioning the ring.

TECH TIP: Using your thumbs to the inside of the ring will help you to achieve an aim for positioning. Try doing this a couple of times before permanent attachment. Once you are ready simply peel the red release liner from the back of the ring and then carefully and slowly position the ring pressing firmly along the entire shape to set.

IMPORTANT NOTE: The top thicker portion of the trim ring will NOT attach to the paint along the bottom of this section and need only be pressed along the top edge. Once you have successfully installed the trim ring peel the top protective liner off.

5. You have been supplied with a length 1/8" chrome trim. This trim has been supplied to finish the edge of your new trim ring. To install it apply a thin bead of adhesive promoter (provided) along the outer edge of the trim ring directly to the paint (this will not harm your paint). Peel a small length of the red release liner from the back of the chrome trim and start at the very bottom <u>center</u> on the trim ring, set the trim and press it along the edge of the ring directly to the paint as you pull the liner until you reach the start point. Snip away the excess trim and set the end into a nice tight butt seam.

TECH TIP: This trim will have a tendency to shrink over time, to compensate for this place a small drop on instant adhesive (not included) to the end of the trim before you set the butt seam. NOTE: Doing this will prevent a gap from forming over time.