

AMERICAN CAR CRAFT

DODGE MAGNUM/CHRYSLER 300/CHARGER/CHALLENGER UPPER HOOD CAP

PART # 153002 patent pending

INSTALLATION INSTRUCTIONS

Your cover comes to you with a protective liner. Do not remove liner until final installation.

1. Remove the two bolts holding in place the hood catch cross bar. (NOTE: IF YOU WILL BE INSTALLING OUR HEADER PLATE BE SURE TO REPLACE THESE BOLTS WITH THE SPECIAL FLAT BOLTS THAT ARE PROVIDED WITH YOUR HEADER PLATE). Set bolts aside.
2. NOTE: A friend would be very helpful for this next step. Placing the cross bar back in position as you place your new insert over it and arrange its position onto the hood so that you can achieve thru access at both hole locations. Replace the cross bar bolts that you just removed.

Thank you and enjoy your purchase!

CARE AND MAINTENANCE:

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.