



AMERICAN CAR CRAFT INSTRUCTION

Pontiac G8 Shock Tower Dome Covers

PART# 223006



PARTS INCLUDED:

2-3/4 Chrome Cap Covers(#4277)

2-Stainless Trim Rings

1-Adhesive Promoter Pack

This 4pc kit has been designed to finish the appearance of the factory shock tower. Although they have been made as a finishing touch for our G8 Full Fender Cover Kit they can stand alone and will decorate an area that otherwise looks very plain.

1. Scrub the tops of the factory cap and rubber washer s clean with alcohol to remove dirt.

2. Swipe the adhesive promoter to the area and allow a few seconds to dry.
3. Peel the red release liner from the back of the stainless ring provided in your kit and press it firmly to the factory rubber washer.
4. Remove the hook and loop fastener attachment cookie from the underside of the decorative chrome cap provided in your kit. Peel the release liner from this cookie and then set it onto of the plastic factory cap. The factory cap is not flat so you will need to form it a little pressing very firmly to set. Remove the protective liner from the stainless ring and then simply set the decorative cap in place.

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT