



AMERICAN CAR CRAFT INSTRUCTIONS

2005-2009 V6 & GT MUSTANG BATTERY COVER

PART#273002 patent pending



PARTS INCLUDED:

STAINLESS BATTERY COVER

1-LARGE ZIP TIE

Your new cover comes to you with a protective liner. Do not remove liner until installation is complete.

1. Your new battery cover is designed to set directly over the stock battery in the battery tray. In order to insure proper fitment it will be necessary to make some adjustments in order to create adequate clearance. On some models there may be a heavy gauge positive wire protruding upwards. Remove this wire and flatten the end lead and reattach. Reroute the positive wire harness so that it routes behind and below the top of the battery.

2. You will notice a heavy wire harness snapped into the battery tray and a negative body ground lead strung across to the shock tower. Temporarily unbolt this ground lead and unsnap the heavy harness and let it drop to the side of the battery tray. Using the large zip tie provided fasten the heavy harness thru the snap hole and fasten the harness so that it runs along the side of the battery tray and just underneath the snap hole. Next fasten the ground lead under the tab it was originally bolted to. Simply bolt it back under running the factory bolt upwards until tight.

3. Once adjustments have been properly made place the battery cover over the stock battery and place it in the notches of the battery tray. Remove protective liner.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

Thank you and enjoy your new purchase.

AMERICAN CAR CRAFT