



AMERICAN CAR CRAFT INSTRUCTIONS

2011-2012 MUSTANG PERFORATED SHOCK TOWER DOMES PART #273023



Parts Included:

8-8mm Nuts

8-Chrome Top Hat Style Caps

2-2pc Perforated Shock Tower Domes

Introduction: These new all stainless covers are the answer to customizing an area of your mustang that generally does not want to be covered! Its perforated top area not only looks good but allows the cover to conform to the top of your shock towers uneven surface providing much needed clearance for the hood.

Liner Information: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Your new stainless covers will only fit one way. The contoured shape has been designed to set around the top of your shock tower so that the seam will line up with the small elongated hole at the top of the shock tower facing the back of the car. Take a moment to determine which cover sets in place and then tweak the oval shape of the cover by hand so that it contours around the shock tower nice and

snug. Once you have set the cover press the top of the cover with some force so that the top area containing the holes set into the factory bolt area.

2. You have been provided with four 8mm nuts for each cover and four chrome top hat style caps. It is important to understand that the nuts supplied will not hold the new cover in place at all but it is the top hats that will actually serve to attach the new covers. Install all four nuts atop the factory studs and snug them down. With all four nuts in place simply tap the four top hats over the new nuts. You will notice that the top hats fit very snug and will work very well to hold the new covers permanently in position. Remove the protective liner to finish the installation.

Thank you for your purchase!

AMERICAN CAR CRAFT