



AMERICAN CAR CRAFT INSTRUCTIONS

Polished Upper Hood Cap

Part#303022

Your cover comes to you with a protective liner. Do not remove liner until final installation.

1. Remove the two bolts holding in place the hood catch cross bar. (NOTE: IF YOU WILL BE INSTALLING OUR HEADER PLATE BE SURE TO REPLACE THESE BOLTS WITH THE SPECIAL FLAT BOLTS THAT ARE PROVIDED WITH YOUR HEADER PLATE). Set bolts aside.
2. NOTE: A friend would be very helpful for this next step. Placing the cross bar back in position as you place your new insert over it and arrange its position onto the hood so that you can achieve thru access at both hole locations. Replace the cross bar bolts that you just removed.

Thank you and enjoy your purchase!