



AMERICAN CAR CRAFT INSTRUCTIONS

HHR STAINLESS FRONT BUMPER CAP

PART # 422001

PARTS INCLUDED:

- ___ 1-2pc Stainless Front Bumper Cap
- ___ 1-Adhesive Promoter Pack
- ___ 1-Adhesive Promoter Tube
- ___ 1-Length of 1/8" Chrome Trim-69"

Your new cover comes to you with a clear protective liner do not remove this cover until installation prompted by instructions.

This two section cover is designed to cap the pronounced flat area of the upper bumper area giving your HHR a nice OEM looking upgrade.

1. Thoroughly clean the flat upper bumper area with alcohol to remove any wax road grime and dirt. Then swipe the cleaned area once with the adhesive promoter provided.
2. You will notice a center point in the bumper. Accurately mark this center point with a fine pen or pencil. Place either side of the sectional cover in place to familiarize yourself with the placement, and just how you will set the part in position.
3. Once you are clear on the placement remove the red release liner from the back of the cover and set it directly to the center mark and carefully place the cover into position. Apply the opposite side in exactly the same way. Press firmly along the entire installation to set the part then remove the protective liner. Apply a bead of adhesive promoter tube along the edge of the cover directly to the paint. You have been supplied with a length of chrome trim. This trim is to be used to finish the edge of the cover. Peel a small length of the red release liner from one end of the trim and set in position so that the trim caps the edge of your stainless cover and work your way around to the opposite side then snip off any excess trim with a scissor and press firmly along the entire length to set.



Note: EXTRA CARE must be taken when cleaning your stainless trim. It is a good idea to lightly dust your trim with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.