



AMERICAN CAR CRAFT INSTRUCTIONS

HHR STAINLESS FRONT UPPER BUMPER PLATE

PART #422020

PARTS INCLUDED:

- ___1 Stainless Front Bumper Plate
- ___1-Adhesive Promoter Pack
- ___1-Adhesive Promoter Tube
- ___1-Length of 5/8" Chrome Trim 30"
- ___1-Length of 1/8" Chrome Trim 32"

Your new cover comes to you with a clear protective liner do not remove this cover until installation prompted by instructions.

1. Thoroughly clean the front surface of the HHR bumper with alcohol to remove any and all wax and dirt.
2. Test that the bumper is clean enough to attach to by applying a small strip of masking tape to see if you have achieved a tack. If you have, proceed to apply the adhesive promoter provided by swiping the area once. The watery fluid only needs to be applied in a thin swipe. If you have not achieved a tack then clean again until you have.
3. Your new kit is designed to cover the center area of the bumper. Depending on your model you may or may not have a dark center section. It is this section that we will cover with your kit. **IMPORTANT:** Before you stick anything to the bumper place the stainless section in place and pre shape the part so that it matches the contour of the bumper exactly. This will prevent the part from popping out of place long term. **NOTE:** If you consider that metal will not bend by itself than you can expect that if you do a nice job of shaping the part it will stay in place for years to come. Once you are satisfied with the fitment

simply peel the red release liner from the back of the part and then carefully place it in position and then press firmly to set.

4. You have been provided with two length of chrome trim. The thicker length is to be attached to the bumper just underneath the stainless plate. This will sort of create a rolled look to the bottom side of the kit. Clean the area around the entire plate first with household rubbing alcohol then swipe once with the adhesive promoter stick provided. Simply peel the red release liner and set it in place so that it is nice and tight against the stainless section and then trim away any excess length. Press very firmly to set.

5. The thin length of trim is provided to cap the whole installation. Peel the red release liner from the back of the trim and the set it against the paint at the end of the thicker chrome trim and work your way around to the opposite side and trim away any excess. **TECH TIP:** It is the nature of chrome vinyl trim to shrink over time. In order to prevent the ends of the trim from receding due to this shrinking apply a tiny drop of instant adhesive between the trim at the ends of the kit where the two trims meet. Be careful not to allow any of this adhesive to drip onto the paint as this will damage the paint surface. Apply some

Note: EXTRA CARE must be taken when cleaning your stainless trim. It is a good idea to lightly dust your trim with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.