



AMERICAN CAR CRAFT INSTRUCTIONS
HUMMER H2 FRONT GRILLE
PART #492003 Patent Pending



PARTS INCLUDED:

- 1-Stainless Grille
- 1-Adhesive Promoter Pack

YOUR GRILLE COMES TO YOU WITH A PROTECTIVE LINER. DO NOT REMOVE PROTECTIVE LINER UNTIL INSTALLATION IS COMPLETE.

1. You will need to prepare your factory grille for installation by first scrubbing the black plastic area to be mounted with household rubbing alcohol to remove any and all dirt and wax. Once it is completely clean swipe the area once with the adhesive promoter provided.
2. Once the factory grille has been properly prepared position the new stainless grille so that the holes line up and you can see where the new grille is to be placed. Also take this time to gently form the grille by hand so that it conforms to the shape of your factory grille without forcing.

3. Once you have preformed the new grille and have become acquainted with the overall positioning you can begin permanent installation by removing the red release liner from the back of the stainless grille and reposition it onto the factory grille. Press firmly to set. Remove protective liner. Do not get wet for 24 hours.

Note: Care must be taken when cleaning your grille. It is a good idea to lightly dust your panel with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT