

ADDICTIVE DESERT DESIGNS

2015 - CURRENT CHEVY 2500-3500 HONEYBADGER FRONT BUMPER INSTALLATION INSTRUCTIONS

PREPARATION STEPS

1. Set emergency brake.
2. You will need the following tools:
 - a. Wrench and Socket
 - b. Ratchet or Air Gun

Note: This installation requires 2 people for best results

3. Included in Kit:
 - a. HoneyBadger Front Bumper
 - b.

INSTALLATION INSTRUCTIONS

1. Remove stock bumper.
2. If you have purchased a light bar to place on your bumper, install them on your bumper at this time.
3. With the help of another person loosely install bumper onto truck using factory hardware.



4. Align bumper and tighten into place.
5. Stand back and enjoy your A.D.D. HoneyBadger Front Bumper!

Looking for dependable off-road bumpers? Rely on Addictive Desert Designs for quality and long-lasting products.