



## **INSTALLATION INSTRUCTIONS**

Clean Shield is designed to eliminate 80% of the debris that gets picked up while driving your Corvette on the street or track. Your Clean Shield will actually save you possible costly engine repairs by stopping debris before it can block the airflow to your radiator and cause engine failure due to overheating.

First, remove the screws from the lower fascia of the front bumper. The stock screws are to be reused to install the Clean Shield. Slide the Clean Shield along the top edge of the air deflector with the screw holes facing forward and the angle facing down. Tuck the rear of the Clean Shield under the air conditioner condenser to hold the shield in place. Replace the five stock screws through the Clean Shield retainer holes and tighten the screws back to place.

Total installation time is 10 minutes.

Find out more about performance suspension parts we have.