

**ADVANCE ADAPTERS INC.**

**P/N: 712586**

**NV4500 TRANS. TO CUMMINS DIESEL  
STOCK REPLACEMENT**

**KIT CONSISTS OF:**

No.	Qty	Part No.	Description
1.	1	712586-BLK	DODGENV4500BELLHOUSINGSTOCKREPLACEMENT
2.	4	725010	1/2-13 x 2" transmission to bellhousing bolts
3.	4	725002	LOCK WASHER 1/2" PLATED

Stock items needed when replacing a Dodge automatic:

Clutch Fork	52087515
Spring clip for fork	4338855
Pivot ball	52087542
Washer behind the pivot ball	6022190

These are all stock Dodge item, we do carry them with this bellhousing under our kit **712586A**

This bellhousing is a stock replacement housing, not a heavy duty housing built for more torque. If you have a Cummins engine that is built, you may want to limit the twisting on the drivetrain.



**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.