ADVANCE ADAPTERS INC. P/N: 716007

CROSSMEMBER MOUNT NV3550 & AX15 TO PEUGEOT RUBBER MOUNT

KIT CONSISTS OF:

| No. | Qty | Part No. | Description |
|-----|-----|------------|---|
| 1. | 1 | 716007-PLT | CROSSMEMBER ADAPTER PLATE |
| 2. | 4 | 715523-SP | SPACERS FOR AX15 TRANSMISSION |
| | | | (install between the transmission and the crossmember mount plate use P/N 724323) |
| 3. | 2 | 724303 | 7/16" LOCK WASHER |
| 4. | 2 | 724304 | 7/16" NUT |
| 5. | 4 | 724322 | 7/16"-14 x 1-1/4" F.H.C.S. |
| 6. | 4 | 724323 | 7/16"-14 x 1-1/2" F.H.C.S. |

This is an adapter mount that bolts to the NV3550 or AX15 transmission and allows you to retain the stock Peugeot muffler support and rubber mount. This plate offsets the Peugeot rubber mount forward from the NV3550 or AX15 mount holes to line the rubber mount with the stock slots in the crossmember. The stock slots in the crossmember support may need to be elongated slightly.





Do not over torque the 7/16 nut to stud on this plate (35 Ft-Lbs Max)





SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the <u>assembly of Advance Adapter components</u>. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.