



# **aFe POWER Silver Bullet**

## **Throttle Body Spacer**

**Part Number: 46-33016**

### **INSTALLATION INSTRUCTIONS**

#### **Important!**

**Please verify the parts list and read all instruction steps before you begin installation.**

<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Engine</b>	<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Engine</b>
Ford	Mustang	11-14	V6-3.7L	Ford	F-150	11-14	V6-3.7L

1. Disconnect the breather hose from the intake tube.
2. Loosen the hose clamps securing the intake tube to the throttle body and air box and remove the intake tube.
3. Remove the rubber section of breather hose and clamps from the intake tube.
4. Unbolt the throttle body.
5. Once the throttle body is removed, you are ready to install your Silver Bullet Throttle Body Spacer.
6. Begin by placing the spacer up against the intake manifold with the "AIR IN" side facing out.
7. Place the provided gasket between the throttle body and the spacer and secure using the supplied bolts and washers.
8. Using the supplied hose and clamps reconnect the breather hose to the intake tube.
9. Re-install the intake tube and tighten the hose clamps.
10. Reconnect the breather hose.
11. Your installation is now complete!



#### **Parts List**

- 1 Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 75mm bolts
- 4 6mm flat washers
- 2 Hose clamps
- 1 3" x 3/8" Hose

***advanced FLOW engineering, inc.***