



aFe POWER Silver Bullet

Throttle Body Spacer

Part Number: 46-37006

INSTALLATION INSTRUCTIONS

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine
Honda	Civic SI	06-11	L4-2.0L

1. Disconnect emissions hoses from air intake tube. Loosen air intake tube from throttle body.
2. Remove engine cover. Disconnect the Throttle Position Sensor (TPS) and Electronic Throttle Control (ETC) motor. Unlatch the harness from throttle body.
3. Remove 2 bolts and 2 nuts securing the throttle body to intake manifold. Be sure to prevent loose objects falling into the intake manifold. Remove the two studs from intake manifold, using a stud extractor, or the double nut method.
4. Install a new gasket, Silver Bullet Throttle Body Spacer (engraved side towards throttle body), and the second new gasket onto intake manifold. Bolt this assembly with the longer bolts and washers and torque to 15ft/lb.
5. Reconnect the TPS and ETC harness to the throttle body.
6. Reinstall air cleaner assembly. Reinstall engine cover.
7. Your installation is now complete.



Parts List

- 1 Silver Bullet Spacer
- 2 Gaskets
- 4 8mm x 85mm screws
- 4 5/16" flat washers

advanced FLOW engineering, inc.

Learn more about performance air intake systems we have.