



Silver Bullet

Throttle Body Spacer

PN 46-39002

INSTALLATION INSTRUCTIONS

Important!

Please verify that all parts on the Parts List are included before you begin the installation.

Make	Model	Year	Engine
Audi	A4 (B8)	'09-'16	I4-2.0L (t)
Audi	A5 (B8)	'08-'16	I4-2.0L (t)

1. Remove the engine cover, and locate the throttle body on the driver-side of the engine.
2. Loosen the clamp at the throttle body with a 7mm nut driver, and disconnect the rubber boost tube from the throttle body.
3. Remove the (4) screws that secure the throttle body to the intake manifold using a T30 Torx driver.
4. Make sure that both O-rings are in place on the intake manifold and the new Silver Bullet throttle body spacer. Insert the new Silver Bullet spacer between the intake manifold and the throttle body with the "Air In" side facing the throttle body. Make sure to line up the two pins with the smaller holes on the throttle body spacer.
5. Using the new 70mm screws provided, and a 10mm nut driver, resecure the throttle body and Silver Bullet spacer to the intake manifold. Tighten the screws to 49 in/lb. Do not torque over 49 in/lb. Note that this is a plastic manifold and does not require extreme torque.

CAUTION: Over torque of the throttle body screws can result in intake manifold damage. Advanced FLOW engineering, Inc. will not be responsible for damage to the intake manifold due to over torque of the throttle body screws.

6. Reconnect the boost tube and tighten the clamp with a 7mm nut driver. Reinstall the engine cover.

Your installation is now complete! Make sure to ensure/retighten all of the bolts after 100 miles of driving.



Parts List

- 1 aFe Silver Bullet Spacer
- 1 O-ring Gasket
- 4 70mm screws

Tools Needed

- 7mm Nut Driver
- T30 Torx Driver
- 10mm Nut Driver or
- 10mm Socket and Driver