



INSTALLATION INSTRUCTIONS

MAKE: Dodge
MODEL: 2500/3500
YEAR: 1998.5-2002
ENGINE: L6-5.9L (td) Cummins

Turbocharger (GT Series) 46-60062-1



Parts Included:	Qty	Tools Needed:
• Turbocharger	1	• 15mm Deep Socket
• Gasket, Exhaust Elbow	1	• 13mm Deep Socket
• Gasket, Oil Return	1	• 11mm Deep Socket
• Gasket, Oil Feed	1	• 10mm Deep Socket
• Exhaust Elbow bolts	5	• 10mm Socket
• Gasket, Exhaust Manifold	1	• 8mm Socket
• Exhaust Elbow	1	• 13/16" Wrench
• Stud	2	• 3/4" Wrench
• Oil Injector	1	• 15mm Wrench
		• 13mm Wrench
		• 10mm Wrench
		• 5/16" Nut driver
		• Flat Head Screwdriver
		• Pliers

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on this product. Thoroughly inspect the aFe turbocharger to make sure there is no damage from shipping (if damage is noted, immediately contact aFe customer service).**

1. Disconnect the batteries before starting the installation.
2. Remove air intake system.
3. Disconnect the intercooler pipe from the turbocharger compressor outlet.
4. Disconnect the exhaust downpipe from the turbocharger.
5. Disconnect the oil supply from the top of the turbocharger.
6. Disconnect the oil drain line from the bottom of the turbocharger.
7. Remove the turbocharger from the exhaust manifold.
8. Remove the oil flow restrictor from the top of the O.E. turbocharger.
9. Thoroughly clean the sealing surface of the exhaust manifold outlet on the exhaust manifold.
10. Install the turbine elbow to the back of the aFe turbocharger using the supplied bolts and the supplied gasket.
11. Install supplied studs in the aFe turbocharger.
12. Install the aFe turbocharger using the supplied gasket and the factory hardware.
13. Connect the oil drain line to the bottom of the turbocharger using the supplied gasket and tighten the bolts.
14. Lubricate the turbocharger bearings by inserting supplied oil injector into the oil inlet of the turbocharger.
Spin the compressor wheel by hand to properly lubricate.
15. Install the oil flow restrictor on the aFe turbocharger.
16. Connect the oil feed line to the oil flow restrictor and tighten.
17. Connect the exhaust downpipe to the turbocharger and tighten the two bolts on the flange.
18. Connect the intercooler pipe to the turbocharger compressor outlet.
19. Install the air intake system.
20. Connect the batteries.
21. Double check that all connections are secure.
22. Your installation is now complete. Start the vehicle and verify again that all connections are secure and that you have no leaks. Let idle for 5-10 mins. to allow the aFe turbocharger to properly lubricate before driving.