



## INSTALLATION INSTRUCTIONS

MAKE: Jeep  
MODEL: Grand Cherokee (ZJ)  
YEAR: 96-98  
ENGINE: I6-4.0L

**Cat Replacements**  
**47-48006**



---

**CAUTION:** Allow time for your vehicle to cool down for atleast 2 hours prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

---

- Step 1.** (Read Instructions prior to installation.) Disconnect negative battery terminal.
- Step 2.** Remove O2 sensor. Check if damaged, replace if necessary.
- Step 3.** Unbolt clamps and remove catalytic converter from vehicle.
- Step 4.** Install aFe POWER catalytic converter.
- Step 5.** Connect O2 sensor to aFe POWER catalytic converter.
- Step 6.** Connect negative battery terminal.
- Step 7.** Double check your work, then proceed to start vehicle and check for any leaks.
- Step 8.** Your installation is now complete. It is recommended to re-tighten all exhaust components after 50-100 miles.