



# Magnum Force

Intake System Cover

PN 54-12068

**Important!**

Please read all instruction steps before you begin installation.

| Make | Model | Year      | Engine        |
|------|-------|-----------|---------------|
| Ford | F-150 | 2009-2010 | V8-4.6L, 5.4L |
| Ford | F-150 | 2011-2012 | V6-3.7L       |
| Ford | F-150 | 2011-2012 | V8-5.0L, 6.2L |
| Ford | F-150 | 2011-2012 | V6-3.5L (tt)  |

**Step 1.** Remove your aFe intake kit by disconnecting intake tube from adaptor and remove air intake from air box

**Step 2.** Once on the bench remove trim seal from housing.

**Step 3.** Remove all (5) M6 screws from adaptor from housing keeping adaptor in place.

**Step 4.** Place the cover on the housing and install M6 screws back in place.

**Step 5.** Reinstall housing to air box and attach tube to adaptor.

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



We offer performance air intake systems that are tested to the limit and beyond.