



advanced FLOW engineering

Instruction Manual P/N: 59-20004

Turbo Inlet Pipe

Volkswagen GTI 15-21 L4-2.0L (t)



Qty.	P/N	Part Description
1	05-5920004B	Turbo Inlet Pipe
2	03-50019	Clamp, #44
1	05-01593	Coupling, (3x3)"ID x 3"L

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- Retain factory parts for future use.

1. Disconnect your battery before install.
2. Remove your aFe Power intake tube and coupler.
3. Use a T30 Torx driver to remove the screw holding the turbo inlet and remove the inlet by rotating clockwise.
4. Disconnect the PCV fitting attached to the factory turbo inlet being careful not to crack the plastic pieces.
5. Transfer the O-ring from the factory turbo inlet to your aFe Power turbo inlet.
6. Install your aFe Power turbo inlet, rotating counterclockwise until it locks in place.
7. Reinstall the screw holding the turbo inlet in place.
8. Reconnect the PCV fitting onto your aFe Power turbo inlet.
9. Install the provided aFe Power coupling and clamps.
10. Reinstall your aFe Power intake tube.
11. Reconnect your battery.
12. Installation is now complete.

NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles

Note: Only fits with aFe Power 3" intakes P/N 50-70036, 54-13050, 51/54-76403, and 57-10016