



Intake Kit Installation Instructions: The Universal Offroad Canister XL

Kit Part #	51 /75-11061	Tools Required		Part List:	
Make:	Universal	5/16" nut driver		1 Air Filter P/N (Pro Dry S™ 21-90036 or Pro-GUARD™ 72-90036)	1 Coupling, hump 4" x 4"
Model:		10mm socket w/ ratchet or wrench		1 Housing, rotomold	2 Spacers, nylon
Engine:	Universal	7/16" socket w/ ratchet or wrench		1 Cover, rotomold	3 Screw, hex M6 x 1 x 12
		Flat-head screwdriver		2 Band clamps	5 Screw, button head M6
				1 Snorkel	2 Screw, hex M6 x 1 x 40
				1 Adapter, filter	5 Washer, lock
				1 Cover clip	2 Nut, hex M6
				1 Coupling, hump 4 3/4" x 3"L	5 Washer, flat M6
				2 Clamp, #080	5 Washer, wavy M6
					2 Clamp, #072
					1 Coupling, reducer 4" x 3-1/2"

Step 1



Complete Kit

Step 2



Install button head screws and wavy washers through canister with 5-1/2" adapter.

Step 3



With 10mm socket or wrench, tighten down band clamps with hardware provided. Use 1 flat, 1 lock washer per screw (Make sure nylon spacer is between clamp to keep from collapsing.)

Step 4



Install filter into canister and tighten using 5/16" nut driver. (Use cut out slots to tighten.)

Step 5



Install cover clip with hardware provided, and tighten using 10mm socket or wrench.

Step 6



Line up cover clips to Dzus fasteners and secure cover.

Step 7



Install your snorkel with hump coupler and clamps and tighten. (Snorkel and band clamps can be adjusted)

Step 8



Two couplers are provided to use when installing your canister. (Your choice of what size to use) Check all hoses, clamps and connections periodically. Thank you for choosing aFe!

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50000 gold oil aerosol, or aFe P/N: 90-50500 gold squeeze oil).
Filter Replacement P/N: 72-90036 Pro-GUARD 7™ (black w/gold media) or Pro Dry S™ P/N: 21-90036 (black w/white media) Pro Dry S™ cleaning: see cleaning instruction sheet 06-00074

06-80205