



Silver Bullet

Throttle Body Spacer

PN 46-33020

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine
Ford	Mustang GT	2015-2016	V8-5.0L

- Step 1.** Remove the engine cover in order to gain access to the throttle body.
- Step 2.** Loosen the two clamps on the intake tube. Disconnect all three SAE fittings from the intake tube, and then, using a pair of pliers, remove the spring clamp from the large 1" rubber hose, and proceed to disconnect the rubber hose from the intake tube.
- Step 3.** Using an 8mm socket and ratchet, remove the (4) bolts securing the throttle body. These bolts will not be reused for this installation.
- Step 4.** Install the new **Silver Bullet** Throttle Body Spacer in between the intake manifold and the throttle body. Follow the designation on the front of the throttle body for proper orientation of the spacer. Install the supplied gasket in-between the throttle body and the throttle body spacer.
- Step 5.** Use the supplied hardware to secure the throttle body and spacer to the intake manifold. Use the flat washer, lock washer, and then the M6 bolt for each of the (4) mounting locations.
- Step 6.** Reinstall the intake tube into the vehicle. Connect all (3) SAE connectors, reattach the 1" rubber hose & spring clamp, and tighten both hose clamps to secure the tube.
- Step 7.** Reinstall the engine cover and press down firmly on the mounting points to verify proper installation.

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



Step 1



Step 2



Step 3



Step 4-5



Step 6

Parts List

- 1 **Silver Bullet** Spacer
- 1 Gasket
- 4 M6 flat washers
- 4 M6 lock washers
- 4 M6 x 1 x 70mm bolts

Tool List

- 7mm Socket, 8mm Socket, 10mm Socket, Socket Driver, and Pliers.