



## INSTALLATION INSTRUCTIONS

MAKE: Ford  
MODEL: F-250/F-350  
YEAR: 1995.5-2003  
ENGINE: V8-7.3L (td)

**Turbocharger**  
**Wastegate Actuator**  
**(Street) 46-60078**  
**(GT) 46-60079**



### Parts Included:

- Actuator, Wastegate
- M6 Lockwasher
- M6 Nut

### Qty:

1  
2  
2

### Tools Needed:

- Pliers
- 10mm Socket w/ Ratchet

**CAUTION:** Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on this product.**

1. Remove the nuts (2), E-clip and hose from the OE wastegate actuator.
2. Remove the OE wastegate actuator from the turbocharger.
3. Install the aFe wastegate actuator on the turbocharger using the supplied lockwashers and nuts. Tighten the mounting nuts.
4. Rotate the threaded rod end link on the actuator shaft until the end link will just engage on the wastegate arm pin. Refer to this as the starting point for the following adjustment.
5. Rotate the threaded rod end link clockwise (make the overall rod length shorter) 1 complete rotation. This will set the opening pressure of the wastegate to approximately 40 psi.
6. Tighten the jam nut on the threaded rod to prevent rotation during installation.
7. Direct compressed air (50 psi max) to activate the actuator.
8. Slip the rod end link over the wastegate arm pin.
9. Re-install the E-clip removed in step 1.
10. Reconnect the hose to the wastegate actuator.