

Jeep Wrangler JK Rock Sliders

Remove Front and Rear Doors for Ease of installation

Preparation-

- 1) Set sliders in place, making sure that the sliders are centered around door frames

You Will Need:

- Clamps such as F-clamps or large C-clamps

- 2) Remove the sliders from the vehicle

- 3) Mark all holes for drilling

You Will Need:

- Any device used for marking such as a permanent marker or a scribe

- 4) If possible, center punch the marks you made in step 2 to allow for easier drilling

Drilling-

- 1) Starting with the two holes in the top, very front of the sliders, drill the holes to 5/16"

You Will Need:

- Any sort of drill
- 5/16" twist drill bit

- 2) The rest of the holes must be drilled to 33/64"

You Will Need:

- Any sort of drill
- 33/64" twist drill bit

Installation-

- 1) Set the sliders back in place on the vehicle, making sure that all holes line up

- 2) Starting with the front, top two holes, insert the provided nuts and bolts

You Will Need:

- 5/16" hex bit
- 5/16" wrench

- 3) Moving on to the rest of the holes, insert the provided squeeze nuts

- 4) Using the provided squeeze nut tool, tighten all the squeeze nuts

- 5) Insert the rest of the provided bolts into the squeeze nuts and tighten them in place

You Will Need:

- 5/16" hex bit
- Any sort of impact

Reference Pictures:

