

Affordable Offroad

WJ FRONT INSTALL

DRY FIT BEFORE PAINT OR POWDER COAT



PULL PLASTIC FRONT BUMPER OFF



FIG 1



FIG 2

WITH A CUT OFF WHEEL, CUT TO INSIDE OF FRAME



FIG 3

WJ FRONT INSTALL #2



FIG 4



MAKE SURE ALL BOLTS FIT FRAME HOLES...
THEY MAY NEED TO BE REAMED OUT..

PUT BUMPER TOGETHER & INSTALL