




# ALTERNATOR MOUNT 200R

Small Block Chevy - Passenger Side  
Short Water Pump

**NOTE:**

Install bolt into the water pump first. Then determine the number of spacer washers needed between the bracket and the intake manifold. This will vary with the thickness of the various brands of manifolds. **START ALL BOLTS BEFORE TIGHTENING.**

(We use a belt length of 51 to 52" with this mount on installations in our shop. However; this can vary with the diameter of your pulleys.)



**As with any part of this nature, make sure it fits your application before painting or plating. Parts that have been painted, plated, or modified may not be returned.**