



INSTALLATION INSTRUCTIONS



Choose sections of your vehicle to apply the trim.



Peel off foot long sections of adhesive liner as you apply the trim.



Thoroughly clean desired section with 50/50 mixture of rubbing alcohol and water. Allow to dry.



In minimal temperatures of 65°F, firmly press trim to desired location.



Cut trim to desired length.



Reapply pressure over the trim to confirm a strong bond.



Masking tape can be applied to your vehicle in the desired location beforehand to provide a guide.



A minimum of 24 hours for bonding is required before washing vehicle.