



INSTALLATION INSTRUCTIONS



Choose sections of your vehicle to apply edge trim.



In minimal temperatures of 65°F, firmly press trim to desired location.



Thoroughly clean desired section with 50/50 mixture of rubbing alcohol and water. Allow to dry.



A minimum of 24 hours for bonding is required before washing vehicle.



Cut trim to desired length.