



Part No. **ALL17022**
 ALL17022-1
 ALL17040
 ALL17040-1
 ALL17042

Titanium Shock Stud Kit For Frame Boss And Spuds

Shock stud kits include four studs and nylon locking half nuts to mount shock to chassis or front axle. ALL17022 studs have 1/2"-20 threads that thread directly into pre-threaded bungs. ALL17040 studs are used with ALL17042 14mm-1.5 tap to create threads in 1/2" thru-bungs that would originally have thru-bolts.

Part No.	Description
ALL17022.....	Stud Kit For 1/2"-20 Threaded Bungs
ALL17022-1.....	Stud w/Nut (Single) For 1/2"-20 Threaded Bung
ALL17040.....	Stud Kit For 14mm-1.5 Threaded Bungs
ALL17040-1.....	Stud w/Nut (Single) For 14mm-1.5 Threaded Bung
ALL17042.....	Tap (14mm-1.5 To Thread 1/2" Non-Threaded Bungs)
ALL17048.....	Black Half Nuts 1/2"-20, 10-Pack



ALL17022



ALL17040



Related Part:

ALL17042.....Sprint Car Metric Frame Tap For ALL17040 Shock Stud Kit, M14x1.5.