



Quick Turn Starter Kit

TECH TIPS

Quick Turn Fastener Measurement Guidelines

To find [A] Fastener Length, add together [B] Spring Reach and [C] Material Thickness [including bracket if applicable]. $A=B+C$

Quick Turn Fastener Selection

- Determine the total thickness of the panels being joined including mounting brackets and the space between the panels, if any.
- Select the proper body length and spring height combination which provides the proper thickness range.

| Part No & [B] | [A] .400" | .450" | .500" | .550" | .600" |
|--|-------------|-------------|-------------|-------------|-------------|
| 1" Springs [C] Total Material Thickness Range | | | | | |
| ALL19300 .250" | .165"-.200" | .215"-.250" | .265"-.300" | .315-.350" | .365"-.400" |
| ALL19310 .325" | .098"-.133" | .148"-.183" | .198"-.233" | .248"-.283" | .348"-.383" |
| 1-3/8" Springs [C] Total Material Thickness Range | | | | | |
| ALL19320 .325" | .105"-.148" | .155"-.198" | .205"-.248" | .255"-.298" | .355"-.398" |
| ALL19330 .375" | .055"-.098" | .105"-.148" | .155"-.198" | .205"-.248" | .305"-.348" |
| ALL19336 .425" | .005"-.048" | .055"-.098" | .105"-.148" | .155"-.198" | .255"-.298" |

