

Pulley Shim Kits

Use shim kits to properly align pulleys. Water pump shims have dual bolt hole pattern to fit most GM and Ford water pumps. Crank pulley spacers are for small block Chevys. Kits include three shims.

Part No.	Description
ALL31064	Water Pump Kit, 1/16", 1/16", 1/8"
ALL31066	Crankshaft Kit, 1/16", 5/64", 1/8"



ALL31064



ALL31066