



## Refueling Tank Installation Instructions

**Required Hardware :** 3/8 x 1 ½-16 bolt = 1 per mounting tab  
3/8-16 nut = 1 per mounting tab  
3/8 flat washer = 2 per mounting tab  
3/8 lock washer = 1 per mounting tab

Place the Refueling Tank in the desired location. If you are installing a combo make sure the lid clears the bed when the toolbox lid is in the open position. Mark a location to drill a 3/8" hole in each of the mounting tabs. Before drilling check to make sure you will not drill into hoses, brake lines, wiring, etc. Drill holesthru mounting tabs and truck bed and fit with 3/8"x1 ½" bolts, flat washer on each side, lock washer and nut. Tighten securely.