



CHEVY CRUZE FUEL DOOR

Part # ABD-1006C / Part # ABD-1006B / Part # ABD-1006TT

INSTALLATION INSTRUCTIONS

Tools Needed:

- None

First, open the stock fuel door. Next, Grab onto the inner edge of the fuel door from the outside (if you use your right hand, your palm is touching the outside face of the fuel door and your fingers are wrapped around the edge furthest away from you and closest to the car). Pull straight toward you (away from the car). The door should “pop” loose and pull smoothly out and off the hinge arm. Line up your new fuel door and slide into place.

That completes the installation of your new ABD Fuel Door.

AMERICAN BROTHER DESIGNS