



**Read complete instructions before installation!
Improper installation may void warranty**



Tools needed: 10mm socket, 7mm socket, trim pin remover, electrical tape, wire splicer.



Step 1: Remove the six 10mm screws located on the top grill.



Step 2: Remove the two top pins with the trim pin remover and then remove the 7mm screw.



Step 3: Pull back the wheel well cover to expose the 10mm bolt holding in the bottom bumper.



Step 4: With the wheel well cover pulled back remove the two 10mm bolts holding the



Step 5: Remove the front bumper from the vehicle.



Step 6: Remove the two 10mm bolts located on the top headlight.



Step 7: Remove the third 10mm bolt located on the bottom corner of the head light.



Step 8: Remove the head light from the vehicle.



Step 9: Unplug the head light wire harness.



Step 10: Locate the two wires on the new Anzo head light. Tan wire (+) and Black wire (-).



Step 11: Locate the two sets of loose wires from the new Anzo light and twist red with blue.



Step 12: Now twist the two black wires together.



Step 13: Now splice the blue and red wire to the tan (+) wire to power the halos and led.



Step 14: Now splice the two black wires into the black wire (-).



Step 15: Plug the wire harness into the new Anzo light and reverse installation steps.



Step 16: Test all functions for proper installation before driving.

