



Description: Head lights

Part Number: 111004-111007-111000-111099-111061

Application: 1988-1998 Chevy Fullsize Truck



Tools needed: 7mm socket, 10mm socket, pliers, electrical tape, wire splicer, phillips screwdriver.



Step 1: Remove the four phillips screw to remove the parking lights.



Step 2: Remove the parking lights from the vehicle.



Step 3: Twist off the parking light bulb sockets.



Step 4: Remove the four 7mm screws holding in the grill.



Step 5: Two 7mm screws are located at the top corners of the grill.



Step 6: The next two 7mm screws are located right above the mesh grill.



Step 7: Pull the tabs up to release the grill from the frame.



**Step 8: Pull the grill away from the vehicle.**



**Step 9: Twist off the corner light socket from the grill.**



**Step 10: Remove the four 10mm screws holding in the headlight assembly.**



**Step 11: Pull the headlight away from the vehicle.**



**Step 12: Unplug the wire harness for the head light.**



**Step 13: Plug in the wire harness socket for the new Anzo head light.**



**Step 14: Reverse the install process.**



**Step 15: Test all functions before driving.**

*AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*