



Description: Tail light

Part Number: 211017-211018-211019-211140-211144

Application: 1988-1998 Chevy Full-size - GMC Pick-up/ 1992-1994 GMC
Jimmy - Chevy Blazer FS / 1992-1999 Chevy Suburban - Tahoe- GMC
Yukon-Yukon XL / 1999-2000 Cadillac Escalade



Tools Needed: Phillips
Screwdriver

Step 1: Open the tail gate and
locate the two phillips screw
and remove them.



Step 2: Pull the tail light off
from the vehicle.



Step 3: Unplug the tail light
wire harness.



Step 4: Take ou the new Anzo
tail light from the box.



Step 5: Plug in the tail light
wire harness into the new
Anzo tail light.



Step 6: Test all functions to
make sure of proper
installation before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.