



Completely read all the instructions before installation  
Improper installation will void warranty!

**Step 1**



Tools Needed:  
10mm socket  
7mm Torx wrench

**Step 2**



Remove 2 7mm torx wrench screws located on the top of the tail

**Step 3**



Remove the light carefully towards you and remove the light harness coming out of the tail light

**Step 4**



Remove 2 10mm screws located on each side of the door and carefully remove the tail light towards you

**Step 5**



Install the tail lights by reversing steps 2-4

**Step 6**



Test all functions before operating the vehicle

*AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*