



Description: Taillight
Part Number: 211114, 211115
Application: Nissan Frontier 98-04



Tools needed
10mm socket and ratchet



If you have a bed liner pull it back
and remove the 2 bolts holding
the light in.



Gently remove the light from the
vehicle by pulling outward



Remove the 3 sockets from the
back of the stock light housing



Insert the light sockets in the new
Anzo light housing. The reverse
light will be moved to the center
hole and the turn signal moves
to the bottom hole.



Bolt the new tail light back in place
and test all functions before
operating vehicle.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.