



Description: [Taillight](#)  
Part Number: 211020, 211021, 211022  
Application: Chevy Silverado 03-06



Tools needed  
Phillips Screwdriver



Remove the two screw located  
inside the tailgate jam



Pull the taillight out ward



Remove the 4 light sockets by  
twisting and pulling up



Remove the stickers from the  
light sockets on the back  
of the anzo light



Install the light socket into the  
back of the Anzo light



Install the light and line up the  
screw holes. Screw the two screws  
back in.



Test all functions of the light.