



**Read complete instructions
before installation!
Improper installation may
void warranty**

Description: [Tail Lights](#)
Part Number: 311047-311080-311081
Application: 2007.5-2013 Chevy Silverado



Tools needed: Phillips
screwdriver



Step 1: Under the vehicle bed
unplug the wire harness for the
tail light.



Step 2: unclip the wire from the
plastic clips.



Step 3: Use the phillips
screwdriver to remove the two
screws holding in the tail light.



Step 4: Remove the tail light.



Step 5: Pull the wire out from
under the bed.



Step 6: Peel off the protective
cover from the resistors and
place in the two holes onto the
frame of the body.



Step 7: Plug the resistors in and
the wire harness into the circuit
board under the bed.



Step 8: Test all functions making
sure all functions work before
driving.